

## **TB112 (Rev2) - Mitsubishi a500 Inverter ATC Settings**

---

### **Overview:**

This technical bulletin describes how to set the parameters for the Mitsubishi a500 series inverter and applies to ATC2 and current PLC programs. The previous version of this document applied to the ATC1 PLC program and contained instructions on using vector mode.

### **Inverter Connections:**

R, S, T – 3-Phase Power In

U, V, W – Spindle Motor Power Out

STF - Spindle Forward

STR - Spindle Reverse

RES – Spindle Reset

RH – Spindle Orient

SD - Input Common

2 - 0-10VDC Analog Input

5 - 0-10VDC Common

A - Inverter Fault - (Normally Open)

C - Inverter Fault Common

FU - Orient Complete

RUN - Zero Speed

SE - Inverter Output Common

P, P1 - Braking Resistor

### FR-A5AP Add-on Card Connection

5V – 5VDC from 5<sup>th</sup> axis encoder input and 5VDC to spindle encoder

SG – 5VDC common from 5<sup>th</sup> axis encoder input and 5VDC common to spindle encoder

PA1 - Channel A to 5<sup>th</sup> axis encoder input and channel A from spindle encoder

PA2 - Channel A\ to 5<sup>th</sup> axis encoder input and channel A\ from spindle encoder

PB1 - Channel B to 5<sup>th</sup> axis encoder input and channel B from spindle encoder

PB2 - Channel B\ to 5<sup>th</sup> axis encoder input and channel B\ from spindle encoder

PC1 - Channel Z to 5<sup>th</sup> axis encoder input and channel Z from spindle encoder

PC2 - Channel Z\ to 5<sup>th</sup> axis encoder input and channel Z\ from spindle encoder

**Mitsubishi Inverter Parameter Settings:**Model: **FR-A520-7.5k-NA** and **FR-A5AP** Orientation Control/PLG Feedback optional card

Parameter	Name	Setting
18	High-speed maximum freq.	200 Hz - must set this first to change parameter 1
1	Maximum Frequency	200Hz (4-pole@6000RPM) - see parameter 18
2	Minimum Frequency	0 Hz
3	Base Frequency	60 Hz
7	Acceleration Time	2-5 sec
8	Deceleration Time	2-5 sec
13	Starting Frequency	0 Hz
20	Accel/decel reference frequency	Same as parameter 1
52	DU/PU main display data selection	19 - to monitor encoder position
72	PWM frequency selection	10 - eliminates the metallic sound at low speeds
73	0-5V/0-10V Selection	0
79	Operation Mode Selection	2 - External Operation Mode prevents change of parameters. Set to 1 to change parameters.
80	Motor Capacity	9999
81	Number of Poles	9999
182	RH terminal function	22 - Orientation Start
190	RUN terminal	100 - for negative logic output
194	FU terminal function	27 - Orientation Complete
240	Soft-PWM setting	1 - allows p72 to be set >5
902	Freq. setting voltage bias	Set according to procedure in inverter manual. Commanded speed should be zero (M3S0)
903	Freq. setting voltage gain	Set according to procedure in inverter manual. Commanded speed should be max (M3Smax)
<b>Option Card Settings</b>		
350	Stop position command selection	0 - Internal stop position
355	Dynamic Braking width	12
356	Internal stop position	Depends upon the spindle encoder index pulse in relation to the orientation position.
357	In-position zone	24
358	Orientation Torque	2 – Provides greater torque during orientation
359	PLG rotation direction	1 or 0 depending upon how A/B encoder channel wired
362	Position loop gain	1
369	PLG pulse count	1024, but depends upon encoder cpr
370	Control mode selection	1 - V/F control with PLG feedback
199	Reset to factory defaults	9999

### **Programming Mitsubishi A500 Inverter:**

**Note** - When setting up a Mitsubishi inverter for the first time, set parameter 18 **FIRST**. This allows you to change parameter 1 and set the others without difficulty.

1. Press [MODE] until you see **OPnd** on the screen.
2. Press the up arrow key. You will see **PU**.
3. Press [MODE] until you see **Pr..** on the screen.
4. Press [SET]. You should see P.000 with the first zero flashing.
5. Use the up or down arrow keys to set the first number of the parameter.
6. Press [SET]. The next zero should be flashing.
7. Repeat steps 3 and 4 to set the parameter number.
8. Press [SET]. Set parameter 78 to 1 or (79 to 4) in order to set the other parameters.
9. Use the up or down arrow key to edit the parameter value.
10. Press and hold [SET] for 1.5 seconds to set the value. - Wait for blink
11. Either press [SET] and use the up or down arrow keys to step through the parameters in sequential order or press [MODE] and start from step 1 to set other parameters.
12. Continue until all the parameters have been set. Set parameter 78 back to a 2 or (79 to 2) otherwise you won't be able to get back to **OPND** mode.
13. Press [MODE] until you see **PU** on the screen.
14. Press the down arrow key. You will see **OPND**.

### **Special Parameters:**

Parameters 902 and 903 are slightly different than the rest of the parameters. 902 and 903 have two values in each parameter. Parameter 902 contains the Low Frequency (in HZ) and the corresponding voltage from the PLC for that frequency. Parameter 903 contains the High Frequency (in HZ) and the corresponding voltage from the PLC for that frequency. Parameters 902 and 903 will automatically display the voltage being sent from the PLC when they are set. To do this, follow the procedure below.

### **Setting Parameters 902 and 903:**

1. Put the inverter in PU mode.
2. Change to parameter 902 in the programming mode.
3. The value displayed should be 0.00 HZ. If it is not, use the arrow keys to adjust it to 0.
4. Press and hold [SET] for 1.5 seconds. A beep sounds.
5. Issue an M3S0 command in MDI.
6. Repeat step 4.
7. Change to parameter 903.
8. The value displayed should be the same as parameter 1, 18, or 20, i.e., the maximum output frequency. For the typical 6000RPM setting, it would be 200.0 HZ. The default setting is at 60Hz, so use the arrow keys to set it at 200Hz.
9. Repeat step 4.
10. Issue an M3S6000 in MDI and make sure the spindle override is at 100%.
11. You will notice the display is indicating the voltage, without the implied decimal point. A 100 corresponds to 10.0V for example. It is normal to see the value change slightly, say from 101 to 102.
12. Repeat step 4.
13. Engage E-stop and change the inverter to OPND mode.

#### ATC Override:



**Jog Panel showing location of Aux 12.**

When using the ATC1/2 PLC program, the technician is required to use an override to perform certain M functions when using them from MDI. To perform an M80 or M81 from MDI, the operator must press and hold the AUX12 key on the jog panel prior to entering MDI. The key must continue to be pressed while the custom M functions are used. The Aux 12 key is not labeled but can be seen on the picture above and is marked with the \* directly above the MPG button.

#### Orienting the Spindle for Proper ATC Use:

Parameter # 356 tells the inverter where to position the spindle by encoder counts to properly orient for use with an ATC.

1. Home the machine.
2. Bring the carousel in with an M80 while holding AUX12.
3. Slowly jog the Z-axis down and rotate the spindle by hand until the "half key" is lined up with the notch in the ATC carousel rack.
4. From the run menu on the inverter, press [MODE] until the LED beside MON lights up.
5. Press [SET] to change monitor display. (2 times for encoder counts)
6. Record this number and enter this number in parameter 356.

## ATC Installation Checklist

Once all the Mitsubishi parameters are correct, you must ensure that the relevant ATC parameters are set on the Centroid control.

### *"Umbrella" type tool changers:*

- 1. Power-up and home.
- 2. Air Pressure regulator set at  $\sim 7\text{kg/cm}^2$ .
- 3. Air Pressure switch Range is 90psig.
- 4. Air Pressure switch Differential is 20-25psig.
- 5. Check head mounted unclamp switch for operation with spindle off. Remove any tool.
- 6. Enter manual spindle mode & start spindle at slow speed, check that unclamp switch doesn't work.
- 7. Execute **M80\*** - carousel should come in. Adjust speed and cushioning if needed.
- 8. Execute **M81\*** - carousel should go out. Adjust speed and cushioning if needed.
- 9. Execute **M15\*** - drawbar should unclamp and air blow will come on. Adjust airflow if needed.
- 10. Execute **M16\*** - drawbar will clamp and air blow goes off.
- 11. Execute **M22** - Z axis moves to tool change position.
- 12. Execute **M21** - Z axis moves home.
- 13. Execute **M22** - Z axis moves to tool change position.
- 14. Execute **M19** - Spindle will orient. Check to make sure it is aligned.
- 15. Execute **M80\*** to bring carousel in. Check alignment with ATC tabs.
- 16. Execute **M81\*** to retract carousel.
- 17. Execute **M5** to turn off orient. Move spindle by hand.
- 18. Check the Tool Index + and - functions. Reverse motor operation if needed.
- 19. Use the tool index keys to align tool #1.
- 20. Execute an **M18**, verify "Tool #1 set in ATC" message in the message window.
- 21. Execute a **T2M6**.
- 22. Verify ATC changed to tool #2 – Press **Alt + K** to verify carousel at Bin 2.

\* - **AUX12 must be pressed.**

### *"Swing Arm" type tool changers:*

- 1. Power-up and home.
- 2. Air Pressure regulator set at  $\sim 7\text{kg/cm}^2$ .
- 3. Air Pressure switch Range is 90psig.
- 4. Air Pressure switch Differential is 20-25psig.
- 5. Check head mounted unclamp switch for operation with spindle off. Remove any tool.
- 6. Enter manual spindle mode & start spindle at slow speed, check that unclamp switch doesn't work.
- 7. Execute **M22** - Z axis moves to tool change position.
- 8. Execute **M21** - Z axis moves home.
- 9. Execute **M22** - Z axis moves to tool change position.
- 10. Execute **M19** - Spindle will orient. Check to make sure it is aligned.
- 11. Execute **M5** to turn off orient. Move spindle by hand.
- 12. Check the Tool Index + and - functions. Reverse motor operation if needed.
- 13. Use the tool index keys to align tool #1.
- 14. Execute an **M18**, verify "Tool #1 set in ATC" message in the message window.

- 15. Execute a **T2M6**.
- 16. Verify ATC changed to tool #2.

---

**Document History**

Rev2 Created on 2015-04-29 by #270

Rev1 Created on 2009-12-10 by #240